OMRON

Model FZ-SC2M 2 MEGA PIXEL DIGITAL COLOR CAMERA FOR

MODEL FZ VISUAL INSPECTION SYSTEM

INSTRUCTION SHEET

Thank you for selecting OMRON product. This sheet primarily describes precautions required in installing and operating the product.

Before operating the product, read the sheet thoroughly to acquire sufficient knowledge of the product. For your convenience, keep the sheet at your disposal.



© OMRON Corporation 2007 All Rights Reserved.

PRECAUTIONS ON SAFETY

Meaning of Alert Symbols		
	Indicates a potentially hazardous situation which, if not avoided, will result in minor or moderate injury, or may result in serious injury or death. Additionally there may be significant property damage.	
	Indicates a notantially begandous situation which if not	
	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in property damage.	
Alert statements		
This product is not designed or rated for ensuring safety of persons. Do not use it for such purposes.		

Burn injury may occasionally occur. Do not touch while operating and immediately after turn-off.

PRECAUTIONS FOR SAFE USE

Be sure to respect following items for safety.

(1) Installation Site

- Do not install the product in locations subjected to the following conditions:
- · Ambient temperature outside the rating
- · Rapid temperature fluctuations (causing condensation)
- Relative humidity outside the range of 35 to 85%
- · Presence of corrosive or flammable gases · Presence of dust, salt, or metallic particles
- · Direct vibration or shock
- · Reflection of intense light (such as other laser beams or electric arc-welding machines)
- · Direct sunlight or near heaters
- · Water, oil, or chemical fumes or spray
- · Strong magnetic or electric field
- · Near high-voltage eqipment or power eqipment

(2) Handling the Camera

- Make sure to tighten all installation screws securety The Camera's case is connected to the 0V line in the internal circuits. Observe the following precautions to prevent noise interference.
- · Do not ground the Camera.
- · Do not remove the base attached to the Camera. (3) Others
- Do not use unspecified camera cable and a strobe controller other than those that specified in this manual with the FZ controller. Connection with unspecified camera cable and/or
- strobe controller may malfunction at the worst case. · If you do not use the enhancing connector on the back of the camera,
- do not remove the cap that is attached to the connector. · Do not attempt to dismantle, repair, or modify the main body.
- · If you suspect an error or malfunction, stop using the Controller immediately, turn OFF the power supply, and consult your OMRON representative.
- · Dispose of FZ-SC2M components as industrial waste.

PRECAUTIONS FOR CORRECT USE

Please observe the following precautions to prevent failure to operate, malfunction, or undesirable effect. (1) Connecting Cables

- · Be sure to turn off the power before connecting or disconnecting the cables.
- (2) Optical axis of the Camera.
- The center of the optical axis varies with the camera used. Therefore, when installing the camera, always check the center of (3) Maintenance
- · If large dust particles adhere to the CCD, use a blowerbrush (used to clean camera lenses) to blow them off. Do not blow the dust particles with your mouth.
- · Do not use thinners, benzene, acetone, or kerosene to clean Camera.

Main unit, instruction sheet(this manual)

Specifications

General	specifications

FZ-SC2M
4.0W max.(12V DC,0.34A max.)
10 to 150Hz: half-amplitude: 0.35mm: (maximum acceleration: 50m/s ²), 10 times each in X, Y, and Z directions for 8 min
Shock resistance 150m/s ² ; 3 times each in 6 directions (up/down, left/right, forward/backward)
Operating: 0 to 40 °C (with no icing nor condensation) Storage: -25 to 65 °C (with no icing nor condensation)
Operating and storage: 35% to 85% (with no condensation)
No corrosive gases
IEC60529 IP20 (in-panel)
$X, Y: \pm 0.31 \text{mm} \\ \partial x, \partial y: \pm 2.1^{\circ}$
Cover :Galvanized steel sheet metal Case :Die-cast(ADC-12) Camera mounting base : PC / ABS
Approx. 76g (including base)

Performance specifications

•Feriorinance specifica	auons
Item	FZ-SC2M
	1/1.8-inch interline color CCD
Picture element	(reading all pixels)
Effective pixels	1628(H) × 1236(V)
Pixel size	$4.4(\mu m) \times 4.4(\mu m)$ (Square pixel)
Scanning method	Non-interlace mode
Vertical frequency	30.633Hz
Horizontal frequency	39.352KHz
Pixel frequency	73.636MHz
Number of lines to be	12 lines to 1200 lines
read	
Synchronization	Internal Sync.
Video output	Digital (10 bits)
Gain	0dB to + 16dB
Shutter speed	1/10 to 1/50000s
Lens mounting	C mount

Changing the Camera Base Mount Position

(1) The camera base attached to the bottom of the camera can

the four screws(M2 \times 7) from the base and re-attach the

base to the another side of the camera.(Recommended

If you attach the camera base to the top or side of the

(1) Using the Camera cable FZ-VS (sold separately),

camera connector on Controller FZ series.

Camera cable

FZ-VS

Name plate

connect the connector on the back of the camera and the

*The camera cable (FZ-VS,FZ-VSL,FZ-VSB) is polarized, so,

make sure that the end bearing a name plate is connected to the

screw tightening torque:0.32N·m)

camera, attach with three screws.

Connecting

Controller.

also be attached to the another side of the camera, Remove

Dimensions





(Unit:mm)

Suitability for Use

THE PRODUCTS CONTAINED IN THIS SHEET ARE NOT SAFETY RATED. THEY ARE NOT DESIGNED OR RATED FOR ENSURING SAFETY OF PERSONS, AND SHOULD NOT BE BELIED UPON AS A SAFETY COMPONENT OR PROTECTIVE DEVICE FOR SUCH PURPOSES. Please refer to separate catalogs for OMRON's safety rated products.

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of the products in the customer's application or use of the product.

Take all necessary steps to determine the suitability of the product for the systems, machines, and equipment with which it will be used. Know and observe all prohibitions of use applicable to this product.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS. AND THAT THE OMRON PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

See also Product catalog for Warranty and Limitation of Liability.

EUROPE

Enhancing connector

 \bigcirc

Camera cable

connector

Camera

FZ-SC2M

- OMRON EUROPE B.V. Sensor Business Unit Carl-Benz Str.4, D-71154 Nufringen Germany Phone:49-7032-811-0 Fax: 49-7032-811-199
- NORTH AMERICA
- OMRON ELECTRONICS LLC One Commerce Drive Schaumburg, IL 60173-5302 U.S.A Phone:1-847-843-7900 Telephone Consultation
- 1-800-55-OMRON Fax : 1-847-843-7787
- ASIA-PACIFIC

OMRON ASIA PACIFIC PTE LTD 83 Clemenceau Avenue,#11-01 UE Square,Singapore 239920 Phone: 65-6-835-3011 /Fax: 65-6-835-2711 OMRON Corporation

